



INSTRUCTIONS >

To change lens, push from the inside to the outside.

After removing the lenses you can assemble lenses with another colour. Verify the lens (right or left).

Lenses must be assembled from the outside and not from the inside of the frame. Put the lens in the guide and push up to the click. Press strongly beginning from the external part (that near the temples) until you hear a "click"; check that the lens doesn't go out the frame.

Then assemble the second lens.

Don't put on goggles if the lenses are not well fixed. For doubts of explanations contact our technicians.

Attention : insert first the ventilated okular and after the lens (curve 8).

The change of the lenses must be made with goggles not put on.

Don't use goggles without lenses or with one only lens. Use always lenses with the same colour. Don't use ruined lenses.

To clean goggles and lenses, don't use solvent.